LAVA
create possibilities

KKT Alpha

LAVA
www.lavamobiles.com

User Manual

User Manual
LAVA KKT Alpha

Contents

***1* Preface.....3**

***2* Introduction.....5**

2.1 PHONE DISPLAY.....5

2.2 KEY.....6

***3* Function Menu.....8**

3.1 MAIN MENU.....8

***4* Safety Information and Notices.....12**

***5* Frequently Asked Questions and Troubleshooting.....14**

***6* E-waste Disposal Mechanism.....16**

***7* LAVA WARRANTY CERTIFICATE.....18**

1 Preface

Thank you for purchasing this cellular phone.
To guarantee your cellular phone works properly, please follow the instructions in this manual to prevent any possible incidents or malfunctions.
Follow all safety warnings to avoid injury or property damage.
Screen displays and illustrations in this user's manual are designed to help you operate your phone to its optimum performance.

We continuously strive to improve our products. Therefore, we reserve the rights to revise this user manual or withdraw it at any time without prior notice.

SAR Information

- The highest SAR value for this mobile phone is <1.6 W/Kg, in accordance with the requirements of the ICNIRP,. The recommended s limit for exposure to radio waves is 1.6 watts/kilogram (W/kg) averaged over 1 gram of tissue. For more information, please visit Lava's website www.lavamobiles.comto read about Safety precautions:
- Use a wireless hands-free system (Headphone, headset) with a low power Bluetooth emitter
- Make sure the cell phone has a low SAR
- Keep your calls short or send a text message (SMS) instead. This advice applies especially to children, adolescents and pregnant women
- Use cell phone when the signal quality is good
- People having active medical implants should preferably keep the cell phone at least 15cm away from the implant

Safety precautions:

- Use cell phone when the signal quality is good
- People having active medical implants should preferably keep the cell phone at least 15cm away from the implant

2 Introduction

2.1 Phone Display

2.2 Key

Key	Function
Dial Key	Make or answer a call View Call logs in standby mode.
End Key/ Power Key	Pressing and holding to turn the phone on/off. End a call or reject an incoming call. Return to the idle mode.
LeftSoft Key	Access the Main Menu in idle mode.
RightSoft Key	Access the Contacts list in idle mode. Return to the previous menu. Press and hold it, turn on /off the flashlight.
OK Key	Press to enter main menu in idle mode. After inputting numbers, press this key to do options.
Numeric key	Enter numbers, letters or characters. Select a sub menu item labeled with the corresponding number.
*	Press to toggle between *, +, P, and W. Press to enter symbol when editing text. Press Left soft key then press *, the mobile key

	will be locked.
#	*Press to switch input modes when entering text. Press and hold to change sound profiles to Silent Mode and General mode.*
Navigate Keys	*The user can define your own shortcuts for navigate keys* *Within a menu, press Up, Down, Left and Right to scroll through menu options.*

Note: “Press” in this manual, means to press and release the key; “press and hold” means to press and hold the key for at least 2 seconds.

3 Function Menu

3.1 Main Menu

All function options about the mobile phone are listed as below with brief descriptions

File manager	
To manage the space of memory card, perform the corresponding operation on the selected file and folder	
Phonebook	
New	*To add New Contact*
View	*To view contact info*
Send text message	*To send SMS to contact.*
Call	*To call the contact directly.*
Edit	*Using this option user can edit contact details.*
Delete	*To delete the selected phonebook entry.*
Copy to phone	*To copy the phonebook entries from your SIM card to your mobile.*
Copy to SIM	*To copy the phonebook entries from your mobile to your SIM card*

Add to Blacklist	*you can add an entry in Blacklist, or check call records to select the number you want to set as rejected number.*
Mark several	*To mark or mark all entries for further operations.*
Phonebook settings	*Inside this access several options like Preferred storage, Speed dial, Extra numbers, Memory status, Copy contacts, Move contacts, Delete all contacts*
Audio player	
To play the music	
Call Logs	
-Call logs	
Check call logs for missed, dial, received calls and perform functions like save , delete view etc	
Messaging	
Write Message	*To create a new SMS.*
Inbox	*To view the received messages.*

Drafts	*To save the messages that are not ready to send out in order to further edit, and then send.*
Outbox	*To view the messages in sending or sent unsuccessfully.*
Sent messages	*To view the sent messages.*
Broadcast message	*To receive public messages on all different subjects from your network operator. It needs network support from your SIM provider.*
SMS templates	To view, edit ,remove all templates
SMS settings	*To perform the setting related to SMS .*
Multimedia	
-Image viewer	*To view the saved image.*
-Video Recorder	*To record videos*
-Video Player	*To play the recorded movie.*
-Audio Player	*To play Saved audios*
-Soundrecorder	*To record the sound.*
-FM radio	*You can use the FM radio without the headset as the antenna.*

Settings
-Dual SIM settings
Only SIM 1 open, Only SIM 2 open, Dual SIM open.
- Phone settings
To perform the settings related to mobile phone such as Time and date, power on/off, Language, Display, Flight mode, Misc. settings.
- Network settings
Using this user can do network related settings like New search, Select Network or selection mode
- Security settings
To perform the setting related to security Including PIN, PIN2,Privacy protection, Mobile Tracker.
Restore Settings
Restore all settings as before. Default password:4321
Call settings
All settings related to call like wating,call divert, call barring,blacklist,auto redial, call time display,auto call recorder,call time reminder,call limiter,reject by sms,viberation on call connect
Tools
To perform the features including Bluetooth Alarm, calculator, Calendar, World clock and Torch.

4 Safety Information and Notices

Before using the phone, please read the safety precautions carefully and let your children know these, so that you can use your phone correctly and safely.

Do not switch on your phone when phone use is prohibited or when phone use may cause interference or danger.
Do not use your phone while driving.
Follow the rules or regulations in hospitals and health care facilities. Switch off your phone near medical equipments.
Switch off your phone in an aircraft. The phone may cause interference to control signals of the aircraft.
Switch off your phone near high-precision electronic devices. The phone may affect the performance of these devices.
Do not attempt to disassemble your phone or its accessories. Only qualified personnel are allowed to service or repair the phone.

Do not place your phone or its accessories in containers with strong electromagnetic field.
Do not place magnetic storage media near your phone. Radiation from the phone may delete the information stored on them.
Do not put your phone in a high-temperature place or use it in a place with flammable gas such as a gas station.
Keep your phone and its accessories away from children. Do not allow children to use your phone without guidance.
Use approved batteries and chargers only to avoid explosion.

5 Frequently Asked Questions and Troubleshooting

Frequently Asked Questions	*Cause and Solution*
Fail to turn on	*Press the power on key for over 1 second.* *Check if the battery is properly connected. Please remove and install it again, retry to turn on；* *Check if battery is appropriately charged*
Fail to connect network	*Weak signal. PleaseTry and move to a location with strong signal and try connecting to the network again；* *Please ensure that you are not beyond the network coverage of service providers；* *Please ensure you have a valid SIM card. Please contact your network provider for further information；*

SIM Card Error	*Dirt on the metal surface of an SIM card. Use clean cloth to wipe the metal touch point on an SIM card.* *The SIM card is not installed.* *The SIM card is damaged. Please contact your network service provider.*
Fail to charge	*Poor contact. Please check if the plug is connected well.* *Charge in the environment below 40℃ or above 55℃. Please change your charging environment.* *The battery or charger is damaged. You need to replace it.*

6 E-waste Disposal Mechanism

'E-waste' means waste electrical and electronic equipment (WEEE). In other words E-waste is a popular, informal name for electronic products nearing the end of their "useful life". For more details about e-waste please refer e-waste rules, 2011 www.moef.nic.in

Do's and Don'ts for disposal e-waste

Do's:

- *Ensure that an Authorized Person repairs your Lava products*
- *Call Our Local Authorized Collection Centers to Dispose Lava products*
- *Always drop your used electronic products, batteries or any accessories thereof after the end of their life at nearest Authorized Collection Point or Collection Center.*
- *Separate the packaging material according to responsible waste disposal options and sorting for recycling.*
- *Always remove the battery from the product, when you do not intend to use the product anymore it in future.*

Don'ts

- *Do not Dismantle your Lava Product on your own*
- *Do not give your e-waste to Kabbadi Wala / Scrap*

Dealer/ Rag Pickers.

- *Do not dispose-off the e-waste in landfills*
- *Never dump E-waste in garbage bins.*
- *Do not dispose of your product at municipal waste bins or rooms.*
- *Do not throw used batteries into household waste.*

Consequences of improper handling and disposal of E-Waste

- *Improper disposal of waste prevents natural resources from being re-used.*
- *Some waste contains hazardous chemicals and if not disposed of properly may release toxins into the soil and water, and also releases greenhouse gases into the environment*
- *If e-waste is not properly disposed of, it can threat to the health and well-being of humans and animals and it also has adverse effect on the environment.*
- *Placing of batteries or devices on or in heating devices, such as microwave, ovens, stoves, or radiators and improper disposal of batteries may lead to explosion.*
- *If the battery terminals are in contact with metal objects, it may cause a fire.*

For more details on how to dispose of your Lava products at the end of life, Please refer the list of our Services

Centers on Pan India basis on our website www.lavamobiles.com or please view this link for the details of Service Centers http://www.lavamobiles.com/support-services.

7 LAVA WARRANT Y CERTIFICATE

Limited warranty:

LAVA international Ltd. (LAVA) provides limited warranty for your mobile phone and original accessories delivered with your mobile phone (hereinafter referred to as “product”)

The warranty period for the transceiver is one (1) year and for battery, charger and headset is six (6) months from the date of purchase.

LAVA Warranty

Subject to the conditions of this Limited Warranty, LAVA warrants a product to be free from defects in design, material and workmanship at the time of its original purchase by you, and for a subsequent period of one (1) year for transceiver and six (6) months for battery & charger.

You shall have no coverage or benefits under this warranty in the event that any of the following conditions are applicable:

- The product has been subjected to abnormal use or conditions, improper storage, exposure to 1.excessive moisture or dampness, exposure to excessive temperature, unauthorized modification, unauthorized repair (including but not limited to use of unauthorized spare parts in repairs),abuse, accidents, Acts of God, spills of food or liquids, improper installation
- You have not notified Lava of the defect in the product during the applicable warranty period.
- The product serial no. code or the accessories date code has been removed, defaced or altered.
- The product has been used with or connected to an accessory (i) Not supplied by Lava or its affiliates, (ii) Not fit for use with the product or (iii) Used otherwise than in manner intended.
- The seals of the product's battery enclosure have been broken or shown evidence of tempering or the product's battery has been used in equipment other than that for which it has been specified usable by LAVA.
- All plastic surfaces and all other externally exposed part that is scratched or damaged due to normal use.

To get maximum of your new product, we recommend you to:

- Read the guidelines for safe and efficient use as mentioned in the manual.
- Read the terms and conditions of your Lava warranty in the manual.
- Present this Lava Warranty Certificate along with original proof of purchase whenever you require any warranty services.

In case Lava product needs service, please visit the nearest Lava service centers given in the service guide. Please visit our Website www.lavamobiles.com for updated list of Authorized Service Centers near to your location.

Important note: for your warranty to be valid, all information on the warranty certificate has to be completed including the stamp from the authorized distributor/retailer.

All warranty information, product features and specifications are subject to change without notice.